




Installation (GB)
Installation (F)
Einbauanleitung (D)
Installazione (I)
Installatie (NL)
Instalação (P)
Instalacion (E)
Installation (S)
Montavimo (LT)

Universal Arma-Gard™ (AGS/AGX)


UK office
Elfab Limited
Alder Road, North Shields,
Tyne and Wear, NE29 8SD
UNITED KINGDOM
E: uksales@osecoelfab.com
T: +44 (0)191 293 1234
osecoelfab.com

CE 0343 [P > 0.5 BAR]


1



2




3




4




5




6



7



8



Refer to flange and fastener manufacturer's data.