





**OE5 Plugs**

UK office  
 Elfab Limited  
 Alder Road, North Shields,  
 Tyne and Wear, NE29 8SD  
 UNITED KINGDOM  
 E: [uksales@osecoelfab.com](mailto:uksales@osecoelfab.com)  
 T: +44 (0)191 293 1234  
[osecoelfab.com](http://osecoelfab.com)


- Installation (GB)
- Installation (F)
- Einbauanleitung (D)
- Installazione (I)
- Installatie (NL)
- Instalação (P)
- Instalacion (E)
- Installation (S)
- Montavimo (LT)

CE 0343 [P>0.5Bar]

**1**




**2**





**3**

Do not use if damaged  
 Ne pas utiliser si endommagé  
 Niemals beschadigte berstscheibe einbauen  
 Non utilizzare se danneggiato  
 Indien beschadigd niet gebruiken  
 Nao usar se avanado  
 No utilice en caso de que este danado  
 Far ej anvandas. Om det ar skadat  
 Не пользоваться при повреждениях

- (GB)
- (F)
- (D)
- (I)
- (NL)
- (P)
- (E)
- (S)
- (RUS)




**4**




**5a**

BSPT/NPT




**5b**

BSPP/ISO METRIC



**6**



**7**

Maximum Torque Setting (Nm) (TYPICAL)	
Thread	Torque
ISO METRIC	20
1/4" (Inch)	30
3/8" (Inch)	40
1/2" (Inch)	50