




OE6 Plugs

UK office
Elfab Limited
Alder Road, North Shields,
Tyne and Wear, NE29 8SD
UNITED KINGDOM
E: uksales@osecoelfab.com
T: +44 (0)191 293 1234
osecoelfab.com

- Installation (GB)
- Installation (F)
- Einbauleitung (D)
- Installazione (I)
- Installatie (NL)
- Instalação (P)
- Instalacion (E)
- Installation (S)
- Montavimo (LT)

CE 0343 [P>0.5Bar]


1




2

Do not use if damaged
Ne pas utiliser si endommagé
Niemals beschadigde berstscheibe einbauen
Non utilizzare se danneggiato
Indien beschadigd niet gebruiken
Nao usar se avanado
No utilice en caso de que este danado
Far ej anvandas. Om det ar skadat
He пользоваться при повреждениях


- (GB)
- (F)
- (D)
- (I)
- (NL)
- (P)
- (E)
- (S)
- (RUS)




3




4a




4b



5



6



7

Maximum Torque Setting (Nm) (TYPICAL)	
Thread	Torque
1/4" (Inch)	30
3/8" (Inch)	40
1/2" (Inch)	50