

# Tended device management

Make sure Tended devices are ready for your geofencing projects when needed



## Charge

- Charge devices using the equipment provided by Tended
- Fully charge your device for 6-8 hours ahead of your shift
- Lights will indicate when the device is charging
- Device battery should last around 12 hours

Scan for FAQs



## Store

- If devices have been in storage for a long time, charge them for 8 hours before use
- Devices may need a little longer to boot if they've been in storage for a while, allow up to 10 minutes



## Maintain

- If a device has visible signs of damage do not use it and report to your site manager and Tended
- Follow your organisation's processes for device stock control
- Contact Tended for support

Need more info? Get in touch with our support team



Chat via the help button in your Dashboard



Email  
[support@tended.co.uk](mailto:support@tended.co.uk)



WhatsApp  
[+44\(0\)77136 82625](https://wa.me/4407713682625)