

# Quick start guide: Geotagging

Follow these steps to get started with geotagging for your geofencing projects. Scan the QR codes for more detailed tutorials.

1

## Plan asset locations

Use asset icons to plan the locations of site equipment and machinery.

1. Head to your site map
2. Click "Add asset" and choose your asset icon
3. Click the map to assign the asset to its planned location within your safe zone



2

## Assign devices to the Dashboard

1. Head to the "Devices" tab to view the device management page
2. Click "Add device" then type in the device ID or scan the QR code from the back of each device
3. Assign the device(s) in "Asset mode" for geotagging
4. Choose to give devices nicknames



3

## Start your site & attach devices

Sites need to be live before you connect Tended devices with the Dashboard.

1. Find your project in your Dashboard
2. Click "Start/stop sites", from here you can start, stop and restart sites
3. Attach devices to on-site assets



4

## Review live map

Devices need to be turned on and connected to use the live map view.

1. Head to the "Live map" tab in your project
2. Choose to view asset's live, planned or live and planned locations
3. Click on the live asset icons to follow their locations



5

## Monitor RAG view

See live asset behaviour, including location, speed and distance to a safe zone boundary.

1. Head to the "RAG" tab in your project
2. Monitor your assets on screen
3. Click the location icon to follow the asset on the live map

