


CONSOLE DOCKING STATION WITH COOLING AND CHARGING FUNCTION

FX-XSX-C1-W

User Manual

Product description

1. FX-XSX-C1-W supports Xbox Series S.
2. The kit includes 2 rechargeable batteries to serve as an additional battery for the batteries.
3. The charging indicator will display the battery charging status.
4. Low-noise cooling fans ensure adequate airflow in the console.
5. The fan has 3 different cooling levels.
6. Additional USB-A port, the same as the console's USB.



1. Fan
2. USB-C charging port
3. Charging indicator
4. USB port
5. Power button
6. USB cable
7. Extra battery pack

Technical data

- Base
 - Dimensions: 232 x 184 x 34 mm
 - Weight: 460 g
 - Voltage: DC 5V
 - Operating current: 1.2A
- Battery
 - Dimensions: 56 x 44 x 26 mm
 - Weight: 47g
 - Charging current: 400 mA
 - Battery capacity: 1400 mAh/2.4V

Installation and use



Step 1



Step 2



Step 3






Photo 1



Zdjęcie 2

1. Insert the battery into the controller (Step 1).
2. Place the controller face down in the charging station (Step 2).
3. Place the Xbox Series S console vertically on the stand, connect the USB cable of the stand on the back of the console (Step 3).
4. Turn on the Xbox Series S, the charging indicator will light up green in stand-by mode (Photo 1).
5. While the controllers are charging, the indicator will turn red, when charging is complete, the indicator will turn green (Photo 2).



Fan settings

1. Press once to turn on the fan and set 1 level of cooling
2. Press 2 times to set the 2nd cooling level
3. Press 3 times to set the 3rd cooling level
4. Press 4 times to turn off the fan

Note

1. The charging function supports only the included battery. Charging other batteries and controllers may damage the product.
2. Do not seal the USB-C charging port and avoid contact with water, dirt, etc.

Kit contents

1. Console docking station with cooling and charging function
2. 2x rechargeable battery
3. User manual