

User Manual for the Ex Pro Deeper Smart Sonar Mount

Model: Ex Pro Deeper Smart Sonar Mount

Manufacturer: Exesor 3D Design

Contents:

- 1x Ex Pro Deeper Smart Sonar Mount
 - 1x M5 Thumb Screw
 - 1x GoPro Quick Release
 - 1x Adapter Plate with Adhesive Pad
-

Features:

The Ex Pro Deeper Smart Sonar Mount is designed to securely attach the Deeper Sonar to your watercraft while ensuring optimal sonar performance with minimal interference.

- **Precision Fit:** Specifically designed for Deeper Smart Sonar models.
 - **Easy Handling:** Secure attachment and effortless removal of the Deeper Sonar.
 - **Durable Design:** Manufactured with high-quality carbon fiber composite material for exceptional stability and longevity.
 - **Weather-Resistant:** High chemical and thermal resistance, ideal for outdoor use under harsh conditions.
-

Preparation and Installation:

1. Preparation:

- Ensure that your watercraft is powered off and disconnected from any power sources to avoid accidental activation during installation.
 - Make sure the mounting surface is clean, dry, and free of grease or debris.
-

2. Installation:

Attaching the Ex Pro Mount:

1. Choose a Position:

Select an appropriate location on your watercraft where the mount will be installed. Ensure the surface is clean, dry, and free from contamination.

Note: The Ex Pro Mount is specifically designed for trolling applications. In most cases, it can only be installed at the rear of the watercraft. Front mounting is not supported and may result in reduced functionality.

2. **Attach the Adapter Plate:**

Remove the protective film from the adhesive pad included in the package and attach it to the back of the adapter plate. Press the adapter plate firmly onto the selected spot on the watercraft for at least 15 seconds to ensure a reliable bond.

3. **Secure the Quick Release:**

Attach the provided GoPro Quick Release to the Ex Pro Mount using the M5 thumb screw. Tighten the screw by hand to create a stable connection.

4. **Install the Quick Release:**

Slide the Quick Release with the mounted Ex Pro Mount into the previously attached adapter plate. Ensure it is fully and audibly locked in place to prevent accidental detachment.

5. **Align and Insert the Deeper Sonar:**

Adjust the Ex Pro Mount to ensure the Deeper Sonar is easily accessible and correctly positioned. Carefully insert the Deeper Sonar into the mount. Tighten the anti-drop screw by hand to further secure the Sonar. Ensure the Sonar is stable and does not wobble.

Safety Instructions:

1. Ensure that the Ex Pro Deeper Smart Sonar Mount is properly installed before operating your watercraft.
2. Only use Deeper Sonar models that are compatible with the Ex Pro Mount.
3. Avoid impacts or excessive loads that could damage the mount or the Deeper Sonar.
4. Keep the mount and its components out of reach of children to prevent accidents.

Technical Specifications:

Component	Details
Material	Carbon fiber composite material
Weight	Approx. 32 g
Compatibility	Deeper Smart Sonar (Pro, Pro+, Pro+ 2, Chirp+, Chirp+ 2)
Resistance	High thermal and chemical resistance

Disclaimer:

The manufacturer assumes no liability for damages resulting from improper use, incorrect installation, or modifications to the Ex Pro Deeper Smart Sonar Mount. Please read the instructions carefully and follow them to ensure safe and reliable operation.