

Eugen Hartlieb

Eichenweg 5 74382 Neckarwestheim Mobil.: 015223251171

E-Mail: info@exesor-3d-design.de

Safety Instructions for the BAT-MA Upgrade for Manuowell Assassin Bait Boat

Warning:

These safety instructions apply exclusively to the **Bait Acceleration Technique Manuowell Assassin (BAT-MA)**, which has been specifically developed for the Manuowell Assassin Bait Boat.

Failure to follow these safety instructions may result in material damage, impair product functionality, or lead to injury or harm to individuals. Damages resulting from non-compliance with these instructions are not covered by warranty or guarantee. By using the bait launcher for the first time, the user agrees to the following safety instructions and regulations.

General Instructions:

- Read the operating manual and installation instructions carefully before using the BAT system.
- Use the BAT system exclusively with the Manuowell Assassin and the corresponding ShadowMate XL.
- Ensure that the BAT system is used only with the designated components, including the original remote control and chargers.

Electrical Safety:

- Read the operating manual and installation instructions carefully before using the BAT system.
- Use the BAT system exclusively with the Manuowell Assassin and the corresponding ShadowMate XL.
- Ensure that the BAT system is used only with the designated components, including the original remote control and chargers.

Safety During Use:

- Read the operating manual and installation instructions carefully before using the BAT system.
- Use the BAT system exclusively with the Manuowell Assassin and the corresponding ShadowMate XL.
- Ensure that the BAT system is used only with the designated components, including the original remote control and chargers.

Handling and Maintenance:

- Turn off the BAT system before performing any maintenance or adjustments.
- Clean the system thoroughly after each use to prevent residue buildup and corrosion.

Environmental and Storage Instructions:

- Store the BAT system at temperatures between **-10 °C and 50 °C**. Avoid prolonged direct sunlight to prevent material fatigue.
- Dispose of components such as filament parts and batteries in accordance with local waste disposal regulations.

Emergency Measures:

- Turn off the BAT system immediately if unusual noises, smells, or heat generation occur.
- Do not use the system again until it has been inspected by a qualified technician.

Disclaimer:

- The manufacturer accepts no liability for damages or costs resulting from improper use, modifications to the system, or misuse—including injuries or damages caused by ignoring the safety instructions.
- The use of the BAT system is at the user's own risk.