

## **Eugen Hartlieb**

Eichenweg 5 74382 Neckarwestheim Mobil.: 015223251171

E-Mail: info@exesor-3d-design.de

# Safety Instructions for Deeper Tube Mount (DTM)

## Warning:

The following safety instructions pertain to the Deeper Tube Mount (DTM), which is designed for use with Deeper Smart Sonar models as well as bait boats.

DTM is the core product, while suffixes such as **DTMA**, **DTMB-V2**, **DTMB-V4**, **DTM-ND**, **DTM MA**, **DTMB V** and **DTMU** represent specific mounts for the respective bait boat models.

Be sure to select the appropriate mount for your bait boat to ensure optimal functionality and safety.

Failure to comply with these safety instructions may result in material damage, impairment of product function, and personal injury or damage. Damages resulting from failure to follow these instructions are not covered by warranty or guarantee. By commissioning the DTM, the user agrees to the following safety instructions and terms:

## 1. Assembly and Installation

- Ensure that the bait boat is switched off and disconnected from the power source before beginning the assembly of the DTM.
- Only use the supplied mounting hardware and follow the assembly instructions carefully.
- After assembly, check that all parts (Lower Cover, Tube, Upper Cover) are correctly assembled, and the thumb screw is tightened securely to prevent accidental loosening.

### 2. Using the DTM

- Ensure that the DTM is correctly mounted to the bait boat holder, and the mount on the upper cover is securely connected to the holder.
- Make sure that the DTM and Deeper Smart Sonar are securely held in place to ensure proper function. A loose hold could impair sonar performance or cause loss of the device.

## 3. Safety Precautions on the Water

- Ensure that the DTM is securely mounted to the bait boat before placing the boat in the water. Regularly check that the DTM has not loosened during use.
- In case of strong rocking or waves, extra caution should be exercised to maintain the stability of the DTM.
- Avoid sudden movements or jerks when placing or removing the boat from the water to prevent damage to the DTM and Deeper Sonar.

#### 4. Maintenance and Care

- Clean the DTM regularly with clear water to remove dirt, sand, or deposits.
- Regularly inspect the screw connections and the surface of the tube for cracks or wear.
- Avoid using harsh chemicals or solvents for cleaning to prevent material damage.
- Check the tube for sharp edges and smooth them down if necessary to avoid injury.

#### 5. Environmental Influences

- The DTM is made of high-quality XPETG matte filament, which has excellent mechanical properties. However, avoid extreme heat sources to prevent material deformation or damage.
- Store the DTM in a dry and safe place when not in use, and avoid prolonged exposure to direct sunlight or moisture.
- Dispose of the 3D printed parts and packaging materials in accordance with local disposal guidelines and regulations.

## 6. Avoidance of Injury

- Be cautious of sharp edges that may result from cutting the tube when handling the DTM.
- Keep hands and fingers away from moving or sharp parts of the DTM, especially during assembly and handling.

## 7. Use by Children

- The DTM and associated bait boat should only be used by experienced adults.
- Store the DTM and accessories out of the reach of children to avoid accidents.

#### 8. Disclaimer:

- The manufacturer assumes no liability for damages or injuries resulting from improper use, modifications to the mount, or failure to follow the warning and safety instructions.
- Use of the Deeper Tube Mount (DTM) is at the user's own risk.