



33 Southgate St
Worcester, MA 01610
T: 216-452-1000
F: 508-792-9646
www.absoluterobot.com

ARI Robot Standard Power Requirements

Please Note These Important Disclaimers:

These numbers are for PRELIMINARY and PLANNING purposes ONLY.

These are for STANDARD robot model running at 460 Volts, 3 Phase, 60 Hertz

MOST OPTIONS will increase the max Amp draw

Please Reference the Serial Tag on your machine for the official Amps draw of your robot. The serial tag is usually located on the base of the machine.

Robot Model	Amps (460/3/60)	Recommended Amp Service
MaxA02-650P	8.9	10
MaxA05-1000P	8.9	10
MaxAW05-1100P	8.9	10
MaxBW08-1300P	12.1	15
MaxBW10-1500P	12.1	15
MaxBW15-1700P	14.7	20
MaxBW25-2000P	14.7	20
MaxCW10-1600P	12.1	15
MaxCW15-1600P	12.1	15
MaxCW15-1800P	12.1	15
MaxCW15-2000P	12.1	15
MaxCW25-2500P	13.7	15
MaxCW35-3000P	15.5	20
MaxCW50-3000P	17.6	20



For Additional Support Visit:
<https://support.absoluterobot.com/>