
Designed to easily and safely remove automotive headlight and taillight assemblies, as well as trim items.

 Comes with thin, clear locating strips to identify the location of the guide pins.



- > Locate light cover clips with the plastic strip (Fig. 1)
- > Note location of clips (Fig.2)
- > Use the straight or angled tool to remove and lift up the light cover (Fig.3)
- > Light cover is removed for service (Fig.4)





ANGLE TOOL APPLICATION

- > **Clip 1** could be removed with the straight remover (Fig.5)
- > **Clip 2** with its limited access, could be removed with the angled remover (Fig.6)