


# PIVOT BRACKET

## Installation


### STEP 1:

Remove the upper screw from the pivot mounting bracket.





### STEP 2:

Fix the pivot mounting bracket and mounting profile tightly by the screw.



### STEP 3:


Repeat step 1 & step 2 for the remaining brackets and secure at least 2 locking points for each mounting profile, and the equal interval is more recommended.



**WARNING:** Keep pivot mounting bracket and mounting profile parallel from the side view.


### STEP 4:

Rotate pivot mounting bracket till the showing up of the unfixed screw hole to facilitate the installation with mounting surface as per the pre-marked hole.




### STEP 5:

Fix pivot mounting bracket to mounting surface by KA3.5\*25 screw.



### STEP 6:

Adjust the angle of mounting profile to the one required.



### STEP 7:

Tighten the side screws of pivot mounting bracket to avoid loosened locking point.

