

Partition Wall-Roof Connection

- Notes: 1. Fasteners required to secure the Head Angle to the roof structure are detirmined by the type of roof structure.
 - 2. Install the exterior Head Angle after the panels and mineral wool filler are in place.
 - 3. To conform to the requirements of UL Design No. U042, use silicone sealant.