


User Manual PAR-CT01MAA

Controller Components

Controller Status display/ main display



1	Touch Panel	Operation settings will appear by pressing any switches on the screen
2	ON/OFF button	Press to turn ON/OFF the indoor unit.
3	Setting button	Press to bring the Main menu. When the menu operation is locked, an administrator password is required.
4	◀ button	Press to switch the setting items in the following order: louver, ventilation, vane, fan speed, operation mode, and preset temperature.
5	▶ button	Press to switch the setting items in the following order: preset temperature, operation mode, fan speed, vane, ventilation, and louver.
6	▲ ▼ button	Press to change the contents of the above setting selected in ④ and ⑤ above.
7	Fan speed shortcut button	Press to directly access the fan speed settings screen.
8	Vane shortcut button	Press to directly access the vane settings screen.
9	ON/ OFF	This lamp lights up in green while the unit is in. It blinks while the remote controller is starting up or when there is an error.

When the ON/OFF operation is locked, ② will not be displayed.


When the setting item is switched with the ④ or ⑤ button, if the operation of the selected setting item is locked, the item will not be displayed.

If the operation of the fan speed or vane is locked, the item ⑦ or ⑧ will not be displayed.

The setting contents cannot be changed with the ⑥ button when the setting item is centrally controlled by the system controller.


Controller Components

Controller - Menu Screen



1	ON/OFF button	Press to turn ON/OFF the indoor unit.
2	SELECT button	Press to save the setting.
3	RETURN button	Press to return to the previous screen.
4	MENU button	Press to bring up the Main menu.
5	Function button F1	Menu screen: The button function varies with the screen.

6	Function button F2	Main menu: Press to move the cursor left. Main screen: The button function varies with the screen.
7	Function button F3	Main menu: Press to move the cursor right. Menu screen: The button function varies with the screen.
8	Function button F4	Menu screen: The button function varies with the screen.



Basic Operations

Power ON/ OFF- Button Operation


ON



On the **ON/OFF** button.
The ON/OFF lamp will light up in green, and
the operation will start.

ON/OFF button

OFF




Press the **ON/OFF** button again.
The ON/OFF lamp will come off, and the
operation will stop.

Operation Mode



Each pressing of the  or  button cycles through the following operation modes.

Select the desired operation mode.






Operation modes that are not available to the connected indoor unit models will not appear on the display.

Preset Temperature



Operation mode

Press the  button to decrease the temperature, and press the  button to increase.



The current temperatures will appear. Each pressing of the ◀ or ▶ button switches the temperatures for cooling and heating.

Press the ▼ button to decrease the selected temperature, and press the ▲ button to increase.

Fan Speed

Basic operations

Fan speed



Each pressing of the ▼ or ▲ button cycles through the following fan speeds.



• The available fan speeds depend on the models of connected indoor units.