

User Manual Daikin Madoka Simplified remote controller

Controller Components

1. **On/Off**- Press to start or stop unit
2. **On/ Off status**- Current running state of unit
3. **Status Indicator**- Illuminates when unit first started. De-illuminates after 5 seconds
4. **Set Point**- Required room temperature
5. **Increase**- Press to increase current setpoint
6. **Decrease**- Press to decrease current setpoint
7. **Confirm**- Press to enter user menu



How to use your Madoka Simplified remote controller

By pressing **O** button from the home screen, you will enter the user menu.

A series of icons will be presented, indicating the current status of the unit (actual icon will change to reflect the current status).






Using the **+** or **-** button allows you to scroll through the available settings.

Press the **O** button to enter a setting.

Press the **+** or **-** button allows you to scroll through the available options.

Press the **O** button to confirm the option change and return to the home screen.

N.B. is any icons or options are missing, then the connected air-conditioning unit does not support the function/feature.

				
<p>Time and Date- entering this menu allows you to view current time and date.</p>	<p>Operational mode- A=automatic, Sun= heating, snowflake= cooling, water drops= dry & fan= fan only</p>	<p>Fan speed- 1 bar= low, 2 bars= medium, 3 bars= high and A is automatic</p>	<p>Louver position- white line indicates position, if all are lit then this is swing & A is automation.</p>	<p>Setpoint- Pressing 'O' on this icon returns you to the home screen.</p>