

I'm human



Skullcandy wireless earbuds instruction manual

Skullcandy wireless headphones instructions. Skullcandy wireless earbuds manual. Skullcandy wireless earbuds instructions.

Smokin' Buds User Guide & Troubleshooting FAQs Initial Setup & Pairing Support: Quick Start Guide: First-Time Pairing Out of the Box To pair Smokin' Buds with your device for the first time, remove the stickers from both earbuds, place them in the charging case, and make sure both LEDs show red. Then, take out the earbuds from the case; you'll hear a tone indicating they've powered on, and a voice prompt will say "Ready to Pair." The earbud LEDs will start pulsing red/blue, signaling that both buds are now in pairing mode. Go to your device's Bluetooth settings and look for "Smokin' Buds" among available devices. Select it and accept the pair or OK prompt; when done, a voice prompt will say "connected." Pairing to a 2nd Device (After 1st Time Pairing) While your earbuds are powered on and either disconnected or connected, press the touch sensor on either bud for three seconds. Release when you hear "Disconnected," then "Ready to Pair." If you're currently connected to a device nearby, manually disconnect the Bluetooth on your device; your buds will enter pairing mode directly, also disconnecting from your previously paired device. Open up your device's Bluetooth settings and look for "Smokin' Buds"; select it and accept the pair or OK prompt when done. A voice prompt will say "connected." Quick Start Guide - User Controls Smokin' Buds media controls keep you connected to and in control of your Bluetooth-enabled device. We've added a simple feedback tone feature that lets you hear each time you tap the capacitive touch sensor on your earbud (located on the Skullcandy Logo). Tapping multiple times will give you ascending tones, helping you better manage your media. This is very subtle and won't disrupt your listening; it's easy to hear even while playing music. Auto Power On & Power Off When removing Smokin' Buds from their charging case, you'll hear the power-on "ping" tone, and the LEDs will turn blue for two seconds, indicating they've automatically powered on. When placed correctly back into the charge case, they'll always be powered off as long as the case battery is charged; the LEDs will show solid red to indicate they're powered off and charging. If your earbuds still have a full charge when being placed back into the case, the LEDs will flash red first, then blue for five seconds. PRO TIP: If your Smokin' Buds aren't automatically powering OFF or charging when put into the case or powering ON when removed from it, please Battery Life Tips for Smokin' Buds Earbuds The earbuds in your Smokin' Buds charging case may not be completely drained, but it's essential to know how to manually power them on and off when you put them back into the case. To charge your earbuds, place them in the charging case. If the LEDs turn solid red for 5 seconds, it indicates they are charging. You can close the case lid at any time. Charging Times: - 10 minutes of charging: 2+ hours of playtime - 40 minutes of battery life remain: "Battery Low" voice prompt with flashing red LEDs Manual Controls - Power On/Off: Press and hold touch sensor for 1 second on either earbud - Play/Pause: Tap touch sensor once on either earbud - Answer/Hang Up Call: Tap touch sensor once on either earbud - Reject Incoming Call: Hold touch sensor for 1 second on either earbud - Volume Up/Down: Double tap/take triple tap on the touch sensor on either earbud CASE: The charging case for Smokin' Buds can be charged independently, regardless of whether the earbuds are inside or not. Simply plug in the USB-C Rapid Charge cable and connect it to a computer, wall charger, power bank, or car adapter. A 10-minute charge will provide over 2 hours of battery life. To check the case's battery level, plug in the charging cable; the single LED light next to the USB-C port will indicate the current level: solid red for 0-25%, yellow for 26-75%, and green for 76-100%. If your buds or case aren't charging properly, try cleaning out any debris blocking the charging pins. Check if the in-ear gels are twisted or falling off, which could prevent proper seating. Make sure the charging cable is inserted correctly into a suitable power source. If your earbuds won't automatically power off or charge when placed in the case, ensure the case battery isn't completely drained. If it's dead, the earbuds won't recognize they're in the case and won't turn on when removed. To activate your voice assistant, press and hold the touch sensor for 1 second; Smokin' Buds work with Siri, Bixby, Google Assistant, or any other native assistant. SOLO MODE: Sometimes you want to hear music while still being aware of your surroundings. Use just one earbud in Solo Mode by removing it from the case; both earbuds can be used this way. To return to Stereo Mode, remove the other bud and the audio will seamlessly switch back. FIT: Smokin' Buds fit comfortably and securely in your ear. Place the bud at an angle, then rotate slightly forward or backward to secure it. Ensure a good seal with the eargels by trying out the three sizes included. To find the perfect fit, try out different sizes. Having Trouble? Don't worry, we're here to help! If you're experiencing no audio in one ear, let's re-sync your earbuds. Start by placing both earbuds in the charge case and ensuring both LEDs turn red. Then, remove them together. If that doesn't work, follow these steps: Step One: On your device, disable Bluetooth, remove both earbuds from the case, and ensure they're powered on. Tap the touch sensor on both earbuds six times simultaneously. The earbud LED will slowly flash red/blue, followed by four quick blue flashes indicating a successful true wireless sync. Then, re-enable Bluetooth on your device and select your previously paired "Smokin' Buds. If you still don't have audio streaming in both earbuds or are experiencing pairing issues, proceed to Step Two: Step Two: Clear the device paired list by removing Smokin' Buds from your Bluetooth settings and turning off Bluetooth. Remove both earbuds from the case, and a tone will indicate they're powered on. Press and hold the touch sensor on both earbuds for six seconds until you hear two tones. The LED on both earbuds will flash purple five times, indicating a successful reset. A voice prompt will say "Ready to Pair" as your earbuds enter pairing mode again. FREQUENTLY ASKED QUESTIONS Playtime / Battery Life & Charging: Battery life and play time are crucial. The Smokin' Buds battery lasts up to 8 hours in the earbuds, with an additional 12 hours in the case, allowing for 20 hours of total play time. The total charging time for Smokin' Buds via the included USB-C charging cable is one hour for the case and one hour for the earbuds. Yes, Smokin' Buds features Rapid Charge technology, providing 2+ hours of playtime with just 10 minutes of charging. You can also charge your Smokin' Buds using most USB-A to USB-C charging cables. To change between EQ settings, tap the touch sensor on either earbud when paired to your Smokin' Buds. 4 times to toggle through options: Music Mode (default), Podcast Mode, and Movie Mode. No, Smokin' Buds isn't compatible with the Skullcandy App. Bluetooth range is up to 30+ feet away from paired device, though connection may vary depending on environment. Compatible devices include phone, tablet, MP3 player, laptop, and other devices with Bluetooth connection. Use with PS4/Xbox One/Switch: Xbox One - no, Switch - yes, PS4/5 - no, but possible with separate Bluetooth transmitter dongle. Smokin' Buds uses stereo calling and streaming; hear audio in both ears or use Solo Mode for single earbud. Use Siri/Google Assistant/Alexa by holding touch sensor on either earbud for 1 second when paired to device. Suitable for workouts due to stable fit, sweat, and water resistance (IPX4); dry off before storing. Warranty: Reach out to customer service before filing a claim; likely troubleshoot and solve problem quickly. Manufacturer's defect covered by 1-Year Limited Warranty.