











**SPAREPARTS
AUSTRALIA**

XE Wing Parts Guide




**SIMPLE
PRECISE
RELIABLE**

XE Wing Parts







1010011655	Guide Piece for XE frame Updated part @ 65mm wide 301004255	
1010011660	Plastic Control Steel Guide	
301000449	XE Arm Idler Roller (63mm diameter x 210mm length) - 10 per Arm (20 per spreader) For box of 20 use PN8010000272	
301001267	Actuator for downchutes 01023152 / 1010001965	
301004201	Cylinder for side shift on XESC machines 1010007218	
301004039	Cylinder for New version XE arms 1010012558	
301000729	Cylinder for XE wing fold lock and old version XE arms 01012321 / 1010008281	
1010032930	OMP250 drive motor for XE floor belts	
1010035371	Sequence valve for XE fold ram & locking arms	
1010033379	Temperature & oil level gauge for XE oil tank	
301002453	Oil tank filler cap & breather for XE oil tank on side 03012010 / 1010010339	


301004405	Complete filter for PTO pump 1010016287	
8010000218	Complete edge rubber set for XE machines Suits complete XE unit L&R arms	
1010032680	RHS XE fertiliser downchute complete with scale plate. Including manual lock off.	
1010032679	LHS XE fertiliser downchute complete with scale plate. Including manual lock off.	
301003693	Z Fertiliser Vane (Stainless Steel w/ WC Coating) – 12 per set – Includes bolts	
301003403	X Lime Vane (Red Hardox) – 8 per set (For XE models) – Includes bolts K-Series XE = 18-24m	
301002191	Drive roller for XE arm floor belts 03008154 / 1010011254	
301002192	Tensioner roller fort XE arm floor belts 03008155 / 1010011255	
301004327	XE Frame Nylon Side Shift Roller (Complete kit incl: shaft, bearings & seals). NOT Floor belt roller 1010011668	
301000561	Floor belt 400x5830mm for XE <u>with</u> section control 01010180 / 1010006180	

301000560	Floor belt 400x5580mm for XE <u>without</u> section control 01010175 / 1010003788	
301001431	Guide roller for XE floor belts 02005000 / 1010009022	
301003561	Pin to suit guide roller for XE floor belts 1010008989	
301001432	Floorbelt Guide Roller (Steering Roller) K45 – K135 02005001 / 1010009351	
301003946	Pin to suit floorbelt guide roller K45-K135 1010009350	
1010011658	Nylon side guide roller for XE	
1010011733	Pin to suit nylon side guide roller for XE	
301003799	Plastic cone for small guide roller 02006009 / 1010011256	
1010011634	Plastic scrapers by side guide rollers	
301003631	Scraper nylon 400mm – for XE down chute 301003427 / 1010007683	
1010005586	Scraper V-shape 454mm for underside XE floor belt 301003426 / 301003428	
301001440	Rubber stop for XE fold lock 02006008 / 1010011282	

1010015408	Tab for XE sensor pickup <u>Updated Version</u>	
301000177	Pivot bolt for XE arms with conical washers & nut – Individual M20 x 130	
8010000921	Pivot bolt kit for XE arms including washers, nuts & Bushings One Kit = One Arm	

Down Chutes for XE

1010032680	<u>RHS</u> XE fertiliser downchute complete with scale plate. Including manual lock off.	
1010032679	<u>LHS</u> XE fertiliser downchute complete with scale plate. Including manual lock off.	
1010011269	Funnel with scraper <u>RHS</u> assembly for XE Mounted at end of XE arm	
1010007596	Funnel with scraper <u>LHS</u> assembly for XE Mounted at end of XE arm	
1010007848	Lime downspout adjustable for XE <u>LHS</u>	
1010008279	Lime downspout adjustable for XE <u>RHS</u>	

1010015062	Lime stop complete assembly for XE Suits left and right XE wings	
------------	---	---