

SoloProtect[®] Button



Raise an emergency “Red Alert” at the touch of a button.

The **SoloProtect Button** is a cost-effective accessory for our mobile app users.

Activate a Red Alert call (Android) or a Red Alert message (iOS) by pressing the Button three times.

Benefits



Wear on a watch, belt clip, lanyard or keyring for optimal convenience.



Overrides your phone's keypad lock to activate a Red Alert call (Android) and a Red Alert message (iOS) when pressed.



Uses your phone's GPS and audio to ensure our operators can quickly locate you and listen in to an incident.



Bluetooth will connect up to 100m away from your phone (supported by Bluetooth 5 and above).



Rechargeable battery. Lasts up to 60 days on one charge.



Vibrates discreetly when activated for additional reassurance.



Water and dust proof to IP66.



Compatible with the SoloProtect mobile app for iOS and Android.

