



Google TV Glossary

Product references: LEAP-NEVE, LEAP-AIR, LEAP-UNA, LEAP-S3+, LEAP-S3+UK, LEAP-S3+V2, LEAP-S3PRO, SRT 41, LEAP-S3, LEAP-S3UK, LEAP-S3+ULTIMATE



Google TV

Glossary of Google TV Features

Add a kid:

- You can create kid profiles so that you kids can only have limited access to apps and contents based on what is defined in the "My Family" option in [Google](#).

Ambient Mode:

- This feature enables your device to display pictures as screen saver. Pictures are provided by Google and an Internet access is required so your device must be either connected to the Wi-Fi or to the network through an Ethernet cable.

Apps:

- This menu regroups all the apps that you have downloaded and added to favourites as well as a search feature to look for new apps and download them.

Artificial Intelligence Super Resolution (AISR):

- AISR is a feature used to set a sharpening filter and black level adjustments for Dolby Vision.

Captions:

- This feature is used to set up the subtitles displayed on your screen (font, size, colour)

Consumer Electronic Control (CEC) Input:

- CEC is a norm that enables HDMI connected devices to communicate with the TV and send/receive command controls. For instance, you can turn up/down the volume or turn on/off your TV by using your TV box or amplifier remote control. You can choose if you want to use this feature or not.

Display Mode:

- You can set the screen resolution of your TV manually or set it to Auto. The auto mode will automatically select the maximum resolution for your TV screen.

Dolby Audio Settings:

- You can set audio mixing to increase accessibility for people that are visually impaired, deaf or partially deaf.

Dynamic Range and Colour Format:

- This setting is automatically defined by your TV screen as the colour format can depend on the specification of your TV screen.

Films:

- This menu offers suggestions of films that you can watch based on the content that you previously watched.

General Interest:

- This file contains some of the most popular streaming services from your country. The content of the folder is defined by Google and the ARCOM. Any of the apps that are inside this folder cannot be added to the favourites.

(Specific to France)

High Dynamic Range Output Mode:

- HDR is the automatic default mode used by TVs and TV boxes that enables your TV and TV box to communicate together to set the best mode based on the specification of your TV.
- For the latest TV that have High Definition, it refers to a technique used to display the details of very bright or very dark scenes. You can set your preferred output mode based on your TV screen specifications, Otherwise, we advise to keep the auto mode.

HDR Policy:

- You can select if the HDR feature is activated, deactivated or adaptive. If you use the adaptive mode which will automatically adapt to your TV screen to provide the best experience. The adaptive option is particularly interesting because some darkest parts of your screen can be light black when activated. You can just try the different to see which one is suitable for you.

Library:

- Your library contains all the films or series that you bought on the different streaming platforms that you are using.

Multi Stream (MS) 12 Preferred Output:

- MS 12 is a new audio bundle for Dolby that includes all the different data stream systems of Dolby such as, Dolby Atmos, Dolby 2.0, Dolby Digital 2 and higher. You can set the preferred output mode for your TV or amplifier.

Power and Energy:

- Activate this feature to set up when and how the auto standby mode must be deactivated or when the screen saver must be activated.

Purchase Authentication:

- This feature helps to prevent unauthorized purchases on your device. In some countries the purchase verification of Google Play Store is being updated and the information displayed can be different based on your device.

Resolution:

- You can set the screen resolution.

Safe Search Filter:

- This feature helps you to filter explicit content that can be displayed in your Google Search Results while at work, at home with children, etc. Explicit contents not only refers to nudity, graphic sex acts, sexually explicit content but also to violence and gore.

Series:

- This menu offers suggestions of series that you can watch based on the content that you previously watched.

Set your device Name:

- You can set the name of your device. This name will be visible by the nearby devices that can connect to Bluetooth to whom you can pair your device with.

Switch Access:

- Enables you to control your Android device with [switch access](#). Switch Access lets you interact with your Android device by using one or several switches instead of the touchscreen. Switch Access can be helpful if you can't interact directly with your device.

Talkback:

- This accessibility feature powered by Google is used to help people that are blind or visually impaired to interact with their device screen easily. By outlining the content displayed in a focus box or by an audio explanation.

Text to speech

- This accessibility feature can be used for visually impaired people to hear the information displayed on the screen

Video Description:

- You can activate this feature if you are visually impaired or blind, so that compatible programs will be described by a voice.

Unknown Sources:

- You can activate this feature to allow the installation of .apk files that does not come from the Google Play Store and which did not pass the Google certification. We do not advise to use this feature as installing files from unknown sources can prevent your device from working or bypass security.