




ASSEMBLY INSTRUCTION




Parts List




A x1




B x1




C x2



D x1



E x1



F x1




1 x12




2 x4



3 x2




4 x1





5 x2

1




2








4



5



6





Operation and Adjustment




Static Load Capacity:
50 kg / (110.2 lbs)

Dynamic Load Capacity:
8 kg / (17.6 lbs)



Attention: It is recommended not to exceed a maximum of 8KG on Desktop to allow for easy lifting.



Lift the paddle for lifting the desktop

Lift the paddle and press the desktop
for downward operation.