

SVEMKO
SILENCERS

USER MANUAL

English



ROGUE SERIES

ROGUE 556

Made in Norway 

Important information

Always make sure that the silencer is properly installed and firmly attached before and during use.

Never use Svemko products before reading the user manual.

Always remove the silencer after use to prevent barrel corrosion.

Always remember to check that it is the correct caliber. The caliber is engraved on silencer.

Always store your firearm and silencer separately in a dry place.

The Rogue muzzle brake and Rogue flash hider is sold separate.

Disclaimer

This information is important for your safety and may affect your responsibilities and legal rights under applicable law. Not following the instruction manual and warnings may result in serious injury to yourself and others and to assets such as firearm, silencer and other equipment, including objects in your proximity.

To the extent permitted by applicable law, Svemko's maximum liability for damage to persons, objects or property caused by the use of Svemko's products is limited to the purchase price you have paid for the product(s). Svemko is only responsible for direct losses that incurred as a result of using our product(s) in a correct manner and in accordance with our instruction manual. Damage to persons, objects or property caused by incorrect use of Svemko's products is not Svemko's responsibility and any loss or damage will not be covered by Svemko. Check and follow local law before buying or operating a silencer.

Warranty

The product has a standard 2-year Warranty against material and manufacturing defects.

You can extend the Warranty to a total of 4 years by registering your product at www.svemko.com.

The Warranty only applies if the silencer is aligned with the bore of the barrel. If its not aligned, do not fire the rifle.

The warranty does not apply if the product has been disassembled or tampered with.

The Warranty does not apply if the product has been modified or attempted to be repaired by anyone other than SVEMKO.

Damage related to incorrect mounting of the silencer on the weapon is not covered by the Warranty.

The Warranty does not apply if the silencer is used incorrectly.

Specification

**Measured from end of flash hider / muzzle brake*

Added length: 114 mm*

Total length: 164 mm

Diameter: 39.7 mm

Max barrel dia.: -

Weight: 295 g

Silencing: 24 - 26 dBC

Rifle type: AR

Surface treatment: Cerakote® C

Max firing rate: 100 shots / 3 min

Material: Titanium, Stainless steel

Country of origin: Norway

Please read these instructions carefully. The Rogue 556 is made for caliber 5.56 NATO and .223 Rem.

Colour / signal word	Meaning
Warning	Possible imminent danger! Non-compliance could lead to death or serious injury.
Caution	Dangerous situation! Non-compliance could lead to minor injuries.
Notice	Non-compliance could lead to material damage.

Warning

- Do not use the silencer on a rifle with a caliber larger than .22.
- Always make sure that the rifle and the silencer are of matching calibers.
- Always treat a weapon as if it was loaded.
- Ensure that a loaded firearm is never left unattended. Firearms and ammunition must be stored separately and securely, preventing access by children or unauthorized persons.
- Protect your eyes and ears during shooting.

Mounting the Rogue Muzzle Brake or Flash Hider

Before assembly, ensure that the barrel threads and caliber match the Rogue muzzle brake / flash hider. If they do not match, do not proceed with the assembly.

Only mount the muzzle brake / flash hider when the firearm is **unloaded**.

Use a torque wrench and clean the threads on the barrel thoroughly.

Muzzle brake only (shims included): To align the muzzle brake, use the engraved line (**Figure 2**) on the muzzle brake and align it so it is faced upwards. You will use included shims to adjust it. First, thread the brake onto the barrel and see where the engraved line stops. Then remove it and add the appropriate amount of shims (they come in three thicknesses, colour-coded by thickness, see table below). You may need to stop a bit before the position then do the final torquing. Adjust until it is correct.

Shims (Muzzle Brake only)	0,05mm (RED)	0,1mm (BLUE)	0,3mm (BLACK)
1/2- 28 UNEF	20°	40°	119°
M15x1	18°	36°	108°
5/8-24" UNEF	17°	34°	102°

Rogue muzzle brake and flash hider: Use the included tool when tightening. We recommend applying 35 Nm and using Loctite 243 or similar.




Figure 1 - Flash Hider




Figure 2 - Muzzle Brake

Flash hider: For M15x1 HK Spigot use the included spigot-spacer and then put on the flash hider.

Muzzle brake: For M15x1 HK Spigot use the shims first then the spigot-spacer and then the muzzle brake.

Figure 3 - Flash Hider





Figure 4 - Muzzle Brake



Mounting the Rogue Silencer


Only mount your silencer if your gun is unloaded.

Check that your semi-automatic rifle is approved for use with a silencer before mounting one.

Ensure that the silencer matches the caliber of the weapon (the caliber specification is engraved on the tube). Before mounting, verify that the flash hider / muzzle brake thread matches the muzzle thread of your weapon. If the threads do not match, the silencer must not be mounted.

Slide the silencer onto the muzzle device until it fully stops, then complete the installation by hand-tightening it 90 degrees with approximately 10–15 Nm.

If the flash hider or muzzle brake is stuck in the silencer, use the backside of the supplied tool (**Figure 5**). It features a hexagonal fitting that matches the rear section of the flash hider or muzzle brake.



Warning

- Only mount and unmount your silencer and flash hider / muzzle brake when your firearm is unloaded.
- Make sure there are no loose parts in the silencer before mounting, do so by shaking it. If there is something loose in the silencer, do not use it.

Caution

- Control that the silencer is aligned with the bore of the barrel. If it is not aligned, do not fire the rifle.

Notice

- Always press and hold the release button on the silencer before attempting to detach the silencer. Forcing removal without unlocking may cause damage to the mechanism.

Usage

Overheating the internal module can permanently damage even Grade 5 titanium and significantly shorten the silencer's lifespan. Between shooting series, always ensure the silencer is correctly and securely fitted.

Always wear suitable eye protection and hearing protection when shooting, and ensure everyone in close proximity is similarly protected.

Firearms can occasionally emit powder gas, smoke, lubricants or metal particles during normal use. Likewise, repeated exposure to shooting noise without hearing protection may cause gradual or permanent hearing loss.

Warning

- The Svemko Rogue 556 has been stress-tested at rates exceeding 100 rounds in 3 minutes to validate product safety. After reaching this maximum stress level of 100 rounds, allow the silencer to cool for approximately 15 minutes to avoid overheating. Failure to comply may result in damage to the weapon or silencer and could cause serious injury.
- A silencer greatly reduces noise, but it doesn't eliminate it — always wear proper hearing protection when you shoot.
- Always wear eye protection when using your silencer

Caution

- After use the silencer may be extremely hot. Make sure that you avoid burn damage to yourself, others, or clothing.

Notice

- Mirage covers impede heat dissipation and can lead to faster heating or even overheating of the silencer. Reduce the maximum shooting series by 50% when using a mirage cover.
- You are responsible for ensuring that the mirage cover can withstand the temperatures it is exposed to. Damage to the silencer's surface caused by failure of the mirage cover is not covered under warranty.

Maintenance

Detach the silencer from the weapon after each use and transport it separately. Ensure the silencer is thoroughly dried before placing it in your gun safe.

Never store a firearm with the silencer attached. Doing so can cause permanent damage to the barrel and the silencer. SVEMKO is not liable for any resulting damage.

The Svetko Rogue 556 cannot be disassembled and must be cleaned in one piece. Use a suitable cleaning solution such as Schletek Silencer Cleaner Evolution or an equivalent product. Fill a container with the cleaning solution and fully immerse the silencer. Let it soak for 30–40 minutes, then drain and rinse thoroughly with hot water.

After cleaning, dry the silencer using compressed air and make sure it's completely dry. Apply a light spray of gun oil on the AccuLock mechanism (**Figure 6**).

Cleaning Intervals: Every 1000 rounds.

Inspect the threads of both the silencer and the flash hider / muzzle brake for any damages. Make sure both threads are greased with Molykote or similar.

Store the silencer in a dry place.




Figure 6

Caution

- Neglecting proper maintenance may result in corrosion that permanently damages the barrel and weakens internal parts of the silencer, potentially causing failure and compromising safety.

www.svemko.com

SVEMKO AS

Fjellskålnesvegen 135
5282 Lonevåg
Norway
NO915312888

Svemko AS © 2026. All rights reserved.