



P & G Professional Mr. Clean® Magic Eraser®—Original



Item # PROC220085

So powerful that each swipe removes more grime than the leading all-purpose spray cleaner.

- ▶ Delivers a powerful clean with water alone to easily remove scuff marks and dirt.
- ▶ Simply wet magic eraser and swipe surface to make these look like new again: walls, baseboards, floors, switch plates, doors, blinds, bathtubs, oven doors, car windshield glass, glass tabletops...
- ▶ Water activated micro scrubbers lift and remove dirt around your site.
- ▶ No Harsh chemicals added.
- ▶ 6 units of 6 pads each.