

● NOTE

- If the unit is off and a command is given other than "Hello Lisa" and "TURN ON", the unit will respond with "Please turn on air conditioner first". If the unit does not recognize a command, it will respond with "invalid command".
- Some modes are powered on in auto mode by default. The temperature cannot be set in fan mode and auto mode. Please change the mode first and then control the temperature.
- When the temperature cannot go any higher, the unit will respond with "Has set temperature to the highest".
- When the temperature cannot go any lower, the unit will respond with "Has set temperature to the lowest".
- Middle speed cannot be set in dehumidifying mode.
- When the wind speed can't go any higher, the unit will respond with "Has set wind speed to maximum".
- When the wind speed can't go any lower, the unit will respond with "Has set wind speed to minimum".
- Strong wind can be set only in cooling and heating mode.
- Fan speed cannot be changed in dehumidifying mode.
- Auto fan speed cannot be set in fan mode or dehumidifying mode.
- When the voice cannot go any higher, the unit will respond with "The volume was turned up to maximum".
- When the voice cannot go any lower, the unit will respond with "The volume was turned up to minimum".
- Fahrenheit command only supports some models, please refer to the actual purchased model for details

VOICE FUNCTIONS INSTRUCTION

● PRECAUTIONS FOR USING VOICE FUNCTIONS

1. Please use English and speak at a moderate and continuous speed.
Fast speed and different regional accents may affect the recognition effect.
2. It is recommended to use voice recognition within a radius of 16 feet (5m).
For best results, face the unit when giving commands. If the distance is too great and if there is a lot of ambient noise in the room, the voice recognition may not function properly.
3. There is a small probability that the voice recognition may falsely activate in a noisy environment.
4. If the voice recognition is not operating properly, try speaking louder or get closer to the unit. Remember to speak slowly, clearly, and face directly at the air conditioner.
5. Turn on/off the Voice function Mode: Use remote control to turn on, dehumidification mode, adjust the temperature to 60°F or 16 °C, and press "-" eight times. (this function only supports some models)

11326001000971

- Carefully read the instruction for safe and correct use of VOICE FUNCTIONS.
- Carefully keep the instruction as it can be referred to at any time.

● VOICE FUNCTION COMMAND WORDS

FUNCTION	THE COMMAND WORD	BROADCAST WORD
Prompt successful Startup	Welcome to use intelligent voice air conditioner	
Wake up the air Conditioner	Hello Lisa	I'm here
Turn off voice	/	The voice function is disabled
Voice function Disabled	/	See you later
Temperature (Fahrenheit degree)	TURN ON	OK, the air conditioner is turned on
	TURN OFF	OK, the air conditioner is turned off
	Sixty degrees	OK, sixty degrees
	Sixty-one degrees	OK, sixty-one degrees
	Sixty-two degrees	OK, sixty-two degrees
	Sixty-three degrees	OK, sixty-three degrees
	Sixty-four degrees	OK, sixty-four degrees
	Sixty-five degrees	OK, sixty-five degrees
	Sixty-six degrees	OK, sixty-six degrees
	Sixty-seven degrees	OK, sixty-seven degrees
	Sixty-eight degrees	OK, sixty-eight degrees
	Sixty-nine degrees	OK, sixty-nine degrees
	Seventy degrees	OK, seventy degrees
	Seventy-one degrees	OK, seventy-one degrees
	Seventy-two degrees	OK, seventy-two degrees
	Seventy-three degrees	OK, seventy-three degrees
	Seventy-four degrees	OK, seventy-four degrees
	Seventy-five degrees	OK, seventy-five degrees
	Seventy-six degrees	OK, seventy-six degrees
	Seventy-seven degrees	OK, seventy-seven degrees
	Seventy-eight degrees	OK, seventy-eight degrees
	Seventy-nine degrees	OK, seventy-nine degrees
	Eighty degrees	OK, eighty degrees
	Eighty-one degrees	OK, eighty-one degrees
	Eighty-two degrees	OK, eighty-two degrees
	Eighty-three degrees	OK, eighty-three degrees
	Eighty-four degrees	OK, eighty-four degrees
	Eighty-five degrees	OK, eighty-five degrees
	Eighty-six degrees	OK, eighty-six degrees
	Eighty-seven degrees	OK, eighty-seven degrees
	Eighty-eight degrees	OK, eighty-eight degrees
	Eighty-nine degrees	OK, eighty-nine degrees
	Ninety degrees	OK, ninety degrees

Temperature (centigrade degree)	Sixteen degrees	OK, sixteen degrees centigrade
	Seventeen degrees	OK, seventeen degrees centigrade
	Eighteen degrees	OK, eighteen degrees centigrade
	Nineteen degrees	OK, nineteen degrees centigrade
	Twenty degrees	OK, twenty degrees centigrade
	Twenty one degrees	OK, twenty one degrees centigrade
	Twenty two degrees	OK, twenty two degrees centigrade
	Twenty three degrees	OK, twenty three degrees centigrade
	Twenty four degrees	OK, twenty four degrees centigrade
	Twenty five degrees	OK, twenty five degrees centigrade
	Twenty six degrees	OK, twenty six degrees centigrade
	Twenty seven degrees	OK, twenty seven degrees centigrade
	Twenty eight degrees	OK, twenty eight degrees centigrade
	Twenty nine degrees	OK, twenty nine degrees centigrade
	Thirty degrees	OK, thirty degrees centigrade
	Thirty one degrees	OK, thirty one degrees centigrade
	Thirty two degrees	OK, thirty two degrees centigrade
Temperature	Temperature up	OK, the temperature has risen
	Temperature down	OK, the temperature has dropped
MODE	Cooling mode	OK, cooling mode
	Heating mode	OK, heating mode
	Dehumidifying Mode	OK, dehumidifying mode
	Fan mode	OK, fan mode
Wind Speed	High speed	OK, high speed wind
	Middle speed	OK, middle speed wind
	Low speed	OK, low speed wind
	Higher wind speed	OK, the wind speed has increased
	Strong wind	OK, strong wind
	Lower wind speed	OK, the wind speed has decreased
	Silent wind	OK, silent wind
	Auto wind	OK, auto wind
Swing Mode	Vertical Swing on	OK, vertical swing is on
	Vertical Swing off	OK, vertical swing is off
	Horizontal Swing on	OK, horizontal swing is on
	Horizontal Swing off	OK, horizontal swing is off
	Swing on	OK, the swing is on
	Swing off	OK, the swing is off
	Increase volume	OK, the volume has increased
VOL	Decrease volume	OK, the volume has decreased
	Maximum volume	OK, maximum volume
	Minimum volume	OK, minimum volume
	Display on	OK, the display is on
Screen Display	Display off	OK, the display is off