



Adjusting Spring Tension on the Melles Griot 63.5mm Shutter

Please refer to attached image of the shutter. You will want to ensure that the shutter return spring is properly seated. This return spring is to the left of the shutter serial number and should be held in tension via the post (circled in green). If the shutter return spring is properly held by the post, you may have to adjust the shutter close assist spring. (Seen circled in red.) There are two screws holding the shutter assist spring. To increase the tension, slightly loosen the two screws holding it in place and move in the direction of the green arrow. Only make small adjustments until the shutter closes normally.

Finally you should exercise the shutter to ensure it works manually.
Please contact FLI for a copy of the video.