

# Navigating Cybersuite X Modules

## Access Control Module

The **Access Control** module in **Cybersuite X** allows you to unlock base-building doors and suite doors using **Bluetooth**. This feature provides secure, keyless entry to your building and unit.

### Steps to Unlock Doors Using Access Control

1. **Ensure that Bluetooth is turned on on your device.**
2. **Open the Cybersuite X App and tap on the "Access Control" module.**
3. You will see a list of available doors that you can unlock.
4. Use the **search bar** to quickly find a specific door.
5. **Tap “unlock”** on the door you wish to unlock, and the system will connect via Bluetooth to grant access.

### Using a Partner Access Module

If your building uses a partner module like DOOR or LATCH, you can:

- **Tap** the partner module (e.g., "Latch") within **Cybersuite X** to **open** the partner app.
- **Access additional features** that may not be available directly within the app, such as providing guest access.
- *Important: You do not need the partner app or a separate partner account to unlock doors via **Cybersuite X**.*

### Notes:

- *Your building management determines which doors are accessible.*
- *If prompted, allow Cybersuite X to access your device’s location.*
- *Bluetooth must be enabled for the app to communicate with the doors.*
- *If you experience difficulty unlocking a door, try:*
  - *Moving closer to the door.*
  - *Ensuring your phone’s Bluetooth is active.*
  - *Restarting the app.*

