

This guide will help you manage your RapidLink SIM services using “Permaconn Connect” web portal.

**Before you start, make sure you have the following:**

- “Permaconn Connect” User Profile + Company Account.
  - No “Permaconn Connect” User profile, follow instructions below.
  - Open your browser, type in **connect.permaconn.com** then click on **Sign Up** to create your “Permaconn Connect” account.
- RapidLink SIM card

**1**

Log in to “Permaconn Connect” URL:  
[connect.permaconn.com](https://connect.permaconn.com)

**2**

From the dashboard, select **RapidLink** on the left-hand menu.




**3**

Click **+ Add Device**.



**4**


Enter the RapidLink SIM's serial number, e.g. S114950 and press **Confirm**.



**5**


**Follow the setup wizard:**

- If required, update the “Display Name”.
- Select the required “Data Pack”.
- Press **Confirm**.
- Note the APN details.
  - Telstra > telstra.m2m
  - Optus > om2moptus



**6**

Once activated, the SIMs management window will appear and you have completed the quick start process



**Contact Us:**

T: 1300 55 66 43

E: [support@permaconn.com](mailto:support@permaconn.com)

W: [permaconn.com](https://permaconn.com)