

This guide will help you manage your IoT SIM services using the Permaconn Connect web portal.

Before you start, make sure you have the following:


- A Permaconn Connect user profile + company account.
- If no Permaconn Connect user profile, follow instructions below:
- Open your browser, type in **connect.permaconn.com** then click on **Sign Up** to create your Permaconn Connect account
- IoT SIM card and stickers.

1 Log in to Permaconn Connect URL:
connect.permaconn.com


2 From the dashboard, select IoT SIM on the left hand menu.



3 Click **+ Add IoT SIM**




4 Enter the IoT SIM's serial number, e.g. S114950 and press **Confirm**.




5 **Follow the setup wizard:**

- If required, update the "Display Name".
- Select the required "Data Pack".
- Press **Confirm**.
- Note the APN details.



6 Once activated the SIMs management window will appear and you have completed the quick start process.




Contact Us:

T: 1300 55 66 43

E: support@permaconn.com

W: permaconn.com