

Install Notes:

1. When using two Sensors, all connections are in Parallel except Supplemental Safety Blue Wire.

2. On Raynor Control, program AUX1 and AUX 2 = (Reversing N.C.).
(Use CLOSE button to page thru choices, Use STOP Button to continue to next option.)

