



Table of Contents

Disclaimer	3
Leo Connect Kit Starlink 2 Setup Instructions	. 4
Starlink Portal Instructions	5



Disclaimer



Starlink cables only fit one way and only into the components they are designed for.

Forceful use and attempting to plug into the wrong ports may cause damage and will not be covered under warranty.



Set Up Instructions

Step 1

Open power box and retrieve power cables.

Step 2

Connect antenna box to power box via connector cable.

Step 3

Connect power box to power source (Plug into the wall, generator, etc)

Step 4

Turn on power via the red switch on the front right of the power box.



Starlink Portal Instructions

Step 1	Search your email that was provided to PEAKE and find your invitation link to the Starlink portal.
Step 2	Once found, click the link and create and/or login to your account.
Step 3	Once logged into the Starlink Portal, navigate to Starlink main page (Three bars on top right > My Account > Dashboard).
Step 4	Schedule date/time with PEAKE engineers for walkthrough of portal functionality.
Step 5	Press power button – located inside, next to the antenna on the base plate.

Contact Peake Support for assistance, if required.

1-800-719-4603

