



English

ARK^x

HEAT YOUR OWN



Charger dock
for ARKx Series S heating device

Heat Your Own Technology®

User guide

Congratulations!

The ARKx Charger Dock allows you to charge your ARKx Series S device so you can enjoy it more frequently throughout the day. The dock functions as both a power bank and a storage case for your ARKx Series S device. This User Guide will guide you in its care and operation.

Safety and precautions

- The device is not designed to be opened by unqualified personnel.
- Do not use the heating device while it is placed in the dock.
- Avoid prolonged exposure to extreme temperatures.
- Do not charge the dock's battery at temperatures below 0°C.
- If the temperature exceeds 40°C, do not charge the battery to 100%.
- **Keep out of reach of minors.**

Charging the dock's battery

- Use the provided cable with a 5V USB-C charger with a minimum current of 2A.
- It is recommended to fully charge the dock's battery before using it for the first time.
- The dock's battery can be charged with or without the ARKx Series S heating device inside.
- When connected, the dock's LED indicators will light up to show that charging is in progress. The flashing LED indicates the current charge level.
- Once charging is complete, all four LEDs will remain lit.

How to use the dock to charge the ARKx Series S heating device

- To charge your ARKx Series S device using the Charger Dock, open it by pressing the lid on the side until it clicks.
- The charging bay will unlock and can be slid outward, exposing the slot where the device should be placed.
- Insert your ARKx Series S device until it is firmly connected. For reference, see the image at the end of this guide.
- When charging begins, the device's LEDs will light up and flash sequentially.
- Once the device is fully charged, its LEDs will stop flashing, and the external LEDs on the charger will turn off.
- The charger can be closed while the device is charging. To close it, press the lid until you hear a click.
- While the device is charging, the dock's external LEDs indicate the battery level.
- If the dock does not respond, you can reset it by pressing the small button located between the LED indicators.

Cleaning

- The charging dock can be cleaned using a damp cloth. Do not use solvents, as they may damage the plastic surfaces..

Warranty

This product is covered against manufacturing defects. If service is required, contact the authorized distributor in your region for information on warranty terms and procedures. Warranty conditions may vary by region.

Filling, packing,
and cleaning tool

ARKx Series S Heating Device
(sold separately)

Storage case



Charge
indicator LEDs

USB-C Charging Port

ARKx
HEAT YOUR OWN

www.arkxway.com