



# Dual Lane Feature & User Guide

## HEADSET FEATURES




## BECOMING L1 RUNNER, PAGING




Insert battery. LED will single flash **GREEN**. Your headset will hear loop detection and paging for both lanes.

## BECOMING L1 ORDER TAKER




Press Lane 1 and Vol + or - LED double flashes **GREEN**.

## BECOMING L2 RUNNER & L2 ORDER TAKER




First press Lane 2 and Vol + or - LED single flashes **BLUE**, you are L2 runner. Press both buttons again, LED double flashes **BLUE**, you are now L2 order taker.

## SINGLE ORDER TAKER BOTH LANES

Press  button on underside of base. All headsets revert to single flash **GREEN**. Become L1 order taker. Then single press L1 or L2 to speak to customer.




## RETURN TO DUAL ORDER TAKER

Press  button on underside of base. To move to L2 runner or L2 order taker, follow step 4 above.




## DRILL THRU TEMPORARY ORDER TAKER



Press and hold L1 or L2 button. Wait for long BEEP. You're then live to customer. Headset reverts to original status after call ends.

## RUNNER & ORDER TAKER SWITCHING LANES



Press both L1 and L2 together. LED colour changes to new group. You have the same role in new group.



Installation Instructions:  
Wall mounted in close proximity  
to the headset charger