

CAPACITIVE SENSORS

DOL 44 and iDOL 44 Capactive Sensors



140107

Plastic gland with flange



140111

Plastic gland with sealing



140109

Sealing for flange



140018

T-Piece universal Ø30 – only for DOL 44 T and iDOL series



140113

Adapter for DOL 40R/PG 36



140100

PG 36 – For DOL 44-33. If combined with 140113 it can be used for DOL 27, 28, 41, 43, 44, and 45.