


Air File FRV-60A



- 1. F-60-01 File Lock Screw
- 4. F-60-04A Piston Extension A
- 5. F-60-05 Support
- 6. F-60-06 Spring
- 7. F-60-07 Spring
- 8. F-60-08A Cylinder A
- 9. F-60-09A Piston A
- 10. F-60-10 Piston Ring

- 11. F-60-11A Limit Ring A
- 12. F-60-12 Ball
- 13. F-60-13A Housing A
- 14. F-60-14 Rear
- 15. F-60-15 O-ring (3 pcs needed)
- 16. F-60-16 Endcap (2 pcs needed)
- 17. F-60-17 Valve Stem
- 18. F-60-18 O-ring

- 19. F-60-19 Ring
- 20. F-60-20 Seal Ring
- 21. F-60-21 Spring Support
- 22. F-60-22 Stop Ring
- 23. F-60-23 Hex Key (Not Shown)
- 24. F-60-24 Inlet Fitting
- 25. F-60-25 Tubing with Fitting