

## QUICK START GUIDE

### XBOX ONE

1. Plug in the PXD to a USB port on the console.
2. System pop-up external device online in your XBOX.
3. Select USB storage devices (The console should already recognize the drive as PXD).
4. The console will tell you the drive needs to be formatted and if you'd like to proceed.
5. Answer Yes, the drive is reformatted.
6. You can choose to set game data stored in the main hard drive or the PXD.
7. To stop using it, user goes to settings and choose "restore game data" in the main hard drive and re-download the game saved to the hard drive.