

Air Cam Walker

Instructions For Use

Step 1. Place foot and leg inside the foam liner and fasten it snugly. Place liner and foot into walker boot.

Step 2. Fasten ankle, foot and calf strap in order. Tighten straps until snug and comfortable.

Step 3. Adjust air cell pressure by squeezing the bulb to inflate.

Step 4. To deflate, press the valve below the inflation bulb.

