



INSTRUCTIONS

AIRPARK™

CODE

↳101717

MAX LOAD

↳10KG / 22LBS

NOTE

Any tool docked on the Airpark greater than 3kg needs to be connected to a structural anchor point.

01

Pass the belt to be used through the belt slot on the back of the Airpark.

02

Slide the Airpark to the desired position on the belt.

03

The tool docked on the Airpark must be attached to an anchor point via a lanyard.