

## How to replace dummy leakage

**Step 1:** Unscrew the top lid to remove the leakage.



**Step 2:** Use the provided tool to remove the leakage.



**Step 3:** Replace the new leakage with the tool and put the lid back on.

