

PINK POT & PAN

Liquid Dish Detergent

Effortlessly tackle grease and grime with our powerful **Pink Pot & Pan** liquid detergent. Tough on stains, yet gentle on hands, it leaves your cookware spotless and your kitchen shining. Enjoy pristine dishes and hassle-free cleaning every time.

Features & Benefits

- Highly concentrated for economical use
- High foaming action with lasting suds
- Provides a fresh clean scent
- Gentle on hands



DIRECTIONS:

Pump or pour 3-4 ounce of **Pink Pot & Pan** into sink. Allow incoming water to generate profuse suds. Use 3-4 ounce of **Pink Pot & Pan** to 9-10 gallons of water. Wash wares, rinse and sanitize as required by local health codes.

PRODUCT INFORMATION

Product Line: **Warewash**

Category: **Dish Detergent**

Matter: **Liquid**

Viscosity: **320-560cp**

Color: **Pink**

Foam: **High Foaming**

Odor: **Fresh Scent**

pH: **8-9**

Available Sizes

Product ID	Case/Size
#500453	4x1 Gallon Case
#500459	5 Gallon Pail



Scan the QR code for product information and Safety Data Sheet

