

Unplugging the EGRcooler

If you are doing emission off tuning for your truck but are leaving the EGRcooler in place, unplug these connectors to not have warning codes

6.7L Powerstroke EGRPlugs to be undone

Step One: On the passenger side of the engine locate the EGR Cooler



Step Two: Undo the plugs circled on the EGRcooler

