

DYNO DIESELS

Unplugging the EGR cooler

If you are doing emissions off tuning for your truck but are leaving the EGR cooler in place, unplug these connectors to not have warning codes

6.4L Powerstroke EGR Plugs to be undone

Step One: The two plugs circled are the only two plugs required to remove located on the front of the engine near the fan shroud

