


# 13HP Compressor/Generator LDV95T Parts Breakdown



Item Number	Parts Descriptions	Part Number
1	Vibration isolation pads	IAT-2NPG6
2	8 Gallon wheel barrow tank	IAT-12-0202
3	Pilot Valve (Pressure control)	IAT-RCB-MHU160/175
4	Tank pressure gauge	IAT-PSB20
5	Drive engine	IAT-GX390
6	Drive engine pulley	IAT-2MLB44
7	Drive engine pulley mounting hub	IAT-LPH1
8	Belt guard	IAT-BG40X20X5N
9	Generator drive belt	IAT-B37
10	Generator drive pulley	IAT-MLB44
11	Generator drive pulley mounting hub	IATLX7/8
12	Generator	IAT-S16W
13	Reciprocating compressor pump	RecipIAT-LDV95T
14	Reciprocating pump drive belt	IAT-B84
15	Reciprocating pump discharge line to tank	IAT-SS1/2X36
16	Reciprocating pump air filter element	IAT-LDV95TAF
17	Manual tank drain	IAT-BDC604-04
18	Tank check valve	IAT-CTJ1234
19	Package wheels	IAT-WHEEL
20	Generator belt tensioning base	IAT-184-D-BE
21	200psi tank safety valve	IAT-ST25-200
22	Tank discharge ball valve	IAT-716116

Part numbers subject to change/update always consult factory prior to ordering



**Compressed Air Systems, LLC**

2626 Skyway Drive  
Grand Prairie, TX, 75052

**Simplicity. It's What We Do.**

Parts Department hours:  
Monday-Friday 8:00 - 5:00 CST

**1-800-531-9656**

Fax 972-352-6364