



---


# ILLUSTRATED PARTS LIST

## TJ-3 COLD BEVERAGE DISPENSER

### MODEL NO.

A8603

A8623



TJ-3 COLD BEVERAGE DISPENSER




FIGURE 1. GENERAL ASSEMBLY



## ILLUSTRATED PARTS LIST

### TJ-3 COLD BEVERAGE DISPENSER

Item No.	Part No.	Name
1	S3169	Spray Tube
	A1620	Impeller Circ Asy Fin Flat Top
	S6737	Impeller Circ Asy Fin A-Frame Top
2	S3402	Housing Pump
3	S1748	Impeller Gray
4		Item Not Used
5	A3058	Impeller and Support Pin
6	A2549	Pin Support Impeller
7	S3273	Bowl
8	S3170	Gasket Bowl
9	S3338	Cover Bowl
10	S4206	Tube Pinch
11	S3354	Gasket Sealing Bowl Spout
12	S4381	Handle Push Asy
	720721601	Label Push Handle
13	S4363	Tube Pinch Spring
14	S4576	Rivet Spr (Pack of 6)
	A3659	Pin Retn (Pack of 6)
15		Item Not used
16		Item Not used
17		Item Not used
18		Item Not used
19		Item Not used
20		Item Not used
21		Item Not used
22		Item Not used
23		Item Not used
24		Item Not used
25		Item Not used
26	A4403	Panel Full Back
27	A7306	Panel Side LH White
	A1727	Panel Side LH Beige
28	A7307	Panel Side RH White
	A1728	Panel Side RH Beige
29	S4554	Screw 1/4
30	A7308	Grille Side LH White
	A2440	Grille w/Filter Side LH White
31	A7309	Grille Side RH White
	A2441	Grille w/Filter Side RH White

Item No.	Part No.	Name
32	S1249	Cord Serv 120V 60HZ
		Cord Serv Specify Country
33	S6750	Magnet Asy
34	S3357 S3358	Spray Asy 115V 60HZ
		Spray Asy 220V 50HZ
35	S1506 S1507	Univ Mtr 115V 60HZ
		Univ Mtr 230V 50HZ
36	S3237	Thermostat
37		Item Not Used
38	S3171 S3361	Motor Asy 115V 60HZ
		Motor Asy 230V 50HZ
39	S3194 S3195	Motor Fan 115V 60HZ
		Motor Fan 230V 50HZ
40	18334	Switch On-Off
41	350125	Cord Serv
42	A7293 S5888	Drip Tray White
		Drip Tray Beige
43	A7295 S6534	Cup Rest White
		Cup Rest Beige
44	S3159	Leg Set
45	S3149	Cover Plate
46	S3362 A1717	Cover Plate Scr (Pack of 6)
		Spacer Switch Plate (Pack of 4)
47		Item Not Used
48	S4080	Panel Fnt
49	S4554	Screw 1/4
50	18367 A8357 A8358 19517 S2472 18837	Spring Armature
		Kit Comp 1/5HP 120V 60HZ
		Kit Comp 1/5HP 230V 50HZ
		Comp 1/5HP 230V 50/60HZ
		Relay 220/240V 50HZ
51	S3067 18572 18547	Start Relay 208/230V 60HZ
		Overld 120V 60HZ
		Overld 230V 50HZ
52	18549	Overld 230V 50/60HZ
		Capacitor Start 230V 60/60HZ (Item Not Available)