




ILLUSTRATED PARTS LIST

JW-5 AND JW-6 COLD BEVERAGE DISPENSER

MODEL NO.

A8706

A8716





ILLUSTRATED PARTS LIST

JW-5 AND JW-6 COLD BEVERAGE DISPENSER




FIGURE 1. GENERAL ASSEMBLY



ILLUSTRATED PARTS LIST

JW-5 AND JW-6 COLD BEVERAGE DISPENSER

Item No.	Part No.	Name
1	18334	Switch On-Off
2		Item Not used
3	S6657	Thermostat
4	S6641	Spray Dr Asy 120V 60HZ
5	S6750	Magnet Asy
6	S6642 S6867	Spray Dr and Fan Mtr 120V 60HZ Spray Dr and Fan Mtr 208/240V 50HZ
7	S6643	Fan Blade
8	S1249 A8354 A8355 A8356	Cord Serv 120V 60HZ Cord Serv (Specify Country) Kit Comp 1/6HP 120V 60HZ Kit Comp 120V 60HZ Kit Comp 208V 60HZ
9	S2220 18388 18567	Relay 120V 50HZ Relay 230V 60HZ Relay 208/230V 60HZ
10	S3067 18390 S4156	Overld 120V 60HZ Overld 220/240V 50HZ Overld 208/230V 60HZ (No Longer Available)
11	A3094	Motor Hs Whipper (No Longer Available)
12	A2410	Magnet Asy Double
13	A2753 S7512 13094	Motor Driv Whipper 120V 60HZ (No Longer Available) Motor Whipper 230V 50HZ Slow Speed Motor Whipper 120V 60HZ
14	S8740 A4510	Plate Switch Cover Asy White (No Longer Available) Plate Switch Cover Asy Black (No Longer Available)
15	S8465 A2754	Switch Whipper Motor, White Switch Whipper Motor, Black
16		Item Not used
17	A7315	Panel Back
18	S3159	Leg set Replacement
19	13933 A6964	Cover Switch Plate Cover Switch Plate Slow Speed (No Longer Available)
20	S9601 18751 A6985 18749	Panel Fnt Asy (Use on Units Below Serial No. 315270; No Longer Available) Panel Fnt Asy (Use on Units Serial No. 315270 and above) Panel Fnt Asy Slow Speed (Use on Units Below Serial No. 315270) Panel Fnt Slow Speed (Use on Units Serial No. 315270 and above)

Item No.	Part No.	Name
21	7215116	Panel Side
22	A7296 18747001	Drip Tray (Use on Units Below Serial No. 315270) Drip Tray (Use on Units Serial No. 315270 and above)
23	18747002	Cup Rest
24	S4554	Screw Panel (Pack of 6)
25	A3060	Screw (Pack of 4)
26	A2081	Spacer Cover Mntg Hdwr
27	S7289	Drain Asy Condensate
28	S8467 14434	Switch Support Asy White (No Longer Available) Switch Spt Asy
29	8468 8469	Washer Star No. 10 Kit Common Parts
30	A4188 A1620 S6737 S6670	Filter Back Panel Impeller Circ Asy Fin Flat Top Impeller Circ Asy Fin A-Frame Top Tube Spray
31	S6677 S7046	Housing Pump Asy 115V 60HZ, 208/230V 60HZ Pump Asy 220/240V 50HZ
32	A3058 A3192	Impeller and Support Pin 115V 60HZ, 208/230V 60HZ Impeller and Support Pin 220/240V 50HZ
33	A2549	Pin Support Impeller
34	S6676	Cover Bowl
35	S6562	Bowl
36	S6600	Gasket Bowl
37	S4206	Tube Pinch
38	S4381 720721601	Handle Push Asy Label Push Handle
39	S4363	Tube Pinch Spring
40	S4576	Rivet Spr Ret (Pack of 6)
41	S6901	Gasket Bowl Spout
42	S7393 A2569	Chamber Whipper Asy (No Longer Available) Chamber Whipper
43	S7394	Tube Vent
44	A0423	Clip Impeller Support
45	A2746	Housing Whipper
46	A0938	Union Whipper Outlet
47	S7395	Outlet Tube
48	A2566	Magnet Whipper Impellaer
49	A0116	Pin Whipper Impeller
50	A7305	Frame Side