




CAUTION - Only trained and certified technicians should service this unit. ALL WIRING AND PLUMBING MUST CONFORM TO NATIONAL AND LOCAL CODES.



Leopard **ERV**TM Base Replacement Guide

Revision: D

 <p>16. Reconnect power connector & replace the cover</p>	<p>17. For Portion Control Valves:</p> <p>Check and verify that portion sizes are correct. If not, perform the manual portion procedure. (Refer to TomCat manual for details. Part No. 620920851INS)</p> <p>For Lever or Pushbutton Valves: Dispense product for 4 to 5 seconds.</p> <p>If problems are encountered, contact Cornelius Technical Support at 1-800-238-3600.</p>			
--	--	--	--	--