

OPERATOR'S MANUAL

ICEMAKER ADAPTOR LID FOR P/N 629083101 OR 629083102

WARNING:

Disconnect power to the unit before servicing. Follow all lock out/tag out procedures established by the user. Verify all power is off to the unit before performing any work.

Failure to comply could result in serious injury, death or damage to the equipment.

CAUTION:

PLEASE UTILIZE STEP LADDER TO ENSURE THAT THE OPERATOR CAN ACCESS THE HOPPER.

Instructions for removal and replacement of the icemaker adaptor lid for manual filling of ice in the hoppers and monthly hopper sanitizing.

After removing the adaptor lid for manual filling of ice in the hopper and monthly hopper sanitizing, follow the step-by-step instructions below to re-install the adaptor lid.

Table 1. Installation of the Adaptor Lid

1. Position lid over the flange of the adaptor kit (Figure 1).




Figure 1.

2. Notice the position of the acorn nut on the adapter kit (Figure 2).




Figure 2.

3. The lid flange has to sit flush to the adaptor between the acorn nuts and the adaptor flanges (Figure 3).



Figure 3.