

ILLUSTRATED PARTS LIST

WM600 AND CM600 ICEMAKER




Figure 1. Unit Exploded View




Figure 2. Unit Exploded View



Table 1. WM600 and CM600 Icemaker-Parts List

Item No.	Part No.	Name
1	630000542	Hopper, Cabinet
2	164005002	Rivet
3	630000520	Rail, Front (Not Shown)
4	50806	Gasket, Motor (Not Shown)
5	50454	Seal, Motor Shaft (Not Shown)
6	70341	Spring, Hopper Gate Slide (Not Shown)
7	30794	Heater, Agitator Motor (Not Shown)
8	630000512	Agitator Motor, 115V (Not Shown)
9	638036269	Clamp
10	25860	Bracket, Agitator Motor (Not Shown)
11	630200719	Angle, Wall Mounting (Not Shown)
12	40914	Fitting, Drain, Drip Tray (Not Shown)
13	630200585	Panel, Bottom (Not Shown)
14	638006070	Tube, Clear, .375 I.D.
15	25929R	Drain Pan Ass'y (Not Shown)
16	169189004	Tubing, PVC (Not Shown)
17	168121001	Sleeve, .163 O.D.
18	50095	Tubing, .250 O.D.
19	630900490	Ice Chute
20	638008837	Gasket, Ice Chute
21	630000521	Wrap, Upper
22	51785	Extension, Ice Chute
23	26083	Adapter Plate
24	52105	Insulation, Cabinet
25	25922R	Panel, Utilities
26	25849R	Wrap, Utility
27	630300265	Wire Harness, Electrical Box
28	03611	Bushing
29	52104	Insulation, Wrapper
30	25861	Agitator Ass'y
31	169071002	Gasket, PVC (Not Shown)
32	630200605	Brace
33	630200557	Tube Drop
34	638036087	Clamp, Dispense Tray
35	638036869-001	Tray, Foam Dispense Ass'y
36	638036883	Cover Ass'y, Dispense Tray
37	638090211	Auger Nut Ass'y

Table 1. WM600 and CM600 Icemaker-Parts List

Item No.	Part No.	Name
38	638090220	Bearing, Delrin
39	638090219	Bearing, Nylon
40	638090217	Head Extruder Ass'y
41	638090213	Auger
42	51891	Gasket, Gate
43	53015	Ice Chute
44	53016	Cover, Ice Chute
45	22476	Spring Retainer, Gate
46	40532	Fitting, 1/4-Bulkhead (Not Shown)
47	630000499	Base, Bottom
48	630300267	Cable Ass'y, Bin Switch
49	630300266	Cable Ass'y, Dispense Mechanism
50	630300268	Cable Ass'y, Motor
51	165697004	Label, Service Valve
52	161903003	Label, Refrigeration Charge
53	165294000	Machine Screw, 1/4-20 By 1-In. Long (Not Shown)
54	164153001	Hex Nut, 1/4-20 (Not Shown)
55	164154000	Washer, .312 I.D. (Not Shown)
56	94100	Wood, 1-In. By 2-In. (Not Shown)
57	638011531	Safety Wire Ass'y
58	638031100-01	Fastener
59	00857	Machine Screw, Phil Truss Hd, No. 8-32 By 3/8-In. Long
60	07667	Machine Screw, Phil Truss Hd, No. 8-32 By 1/2-In. Long
61	35852	Nut, No. 10-32
62	08387	Machine Screw, Phil Truss Hd, No. 10-32 By 1/2-In. Long (Not Shown)
63	168770002	Machine Screw, Hex Hd, No. 5/16-18 By 1/2-In. Long (Not Shown)
64	01051	Hex Nut, No. 10-24
65	168833005	Washer, .204 I.D. (Not Shown)
66	638007051-08	Screw, Phil Hd, No. 10-32 By 5/8-In. Long
67	23981	Hex Nut, No. 10-32
68	165073000	Washer, .203 I.D.
69	164083004	Nut, No. 8-32
70	638000845	Washer



Table 1. WM600 and CM600 Icemaker-Parts List

Item No.	Part No.	Name
71	161173000	Machine Screw, Knurled, No. 8-32 By 1/2-In. Long
72	630900030	Machine Screw, Hex Hd, No. 5/16-18 By 3/4-In. Long
73	638007972-01	Screw, No. 10
74	165384000	Sheet Metal Screw, Hex Hd, No. 8 By 1/2-In. Long
75	03535	Sheet Metal Screw, Sl Phil Hd, No. 10-By 1/4-In. Long
76	161168005	Thread Cutting Screw, Hex Hd, No. 8-32 By 1/2-In. Long
77	638030580	Insulation Tape (Not Shown)
78	169225016	Tubing, Insulation (Not Shown)
79	169225013	Tubing, Insulation (Not Shown)
80	70260	Machine Screw, Phil Rd Hd, 1/4-20 By 1-In. Long (Not Shown)
81	638011480-01	Cable, Compressor
82	638090236	Motor Fan Ass'y, 115V
83	638096723	Fan Blade
84	638036273	Condenser, Air Cool
85	638090635	Shroud, Condenser
86	638090221	Compressor, 115V

Table 1. WM600 and CM600 Icemaker-Parts List

Item No.	Part No.	Name
87	161165008	Capacitor, Start
88	161998009	Relay, 115V
89	161192004	Capacitor, Run, 115V 60HZ
90	30894	Switch, Red Button
91	630900489	Timer, Agitator
92	638004791	Switch, Toggle
93	638031003	Capacitor, Run
94	638031498	Auger, Delay
95	638090052	Relay
96	25815	Panel, Front (Not Shown)
97	26250	Top Panel (Not Shown)
98	31570	Actuator Dispense Switch (Not Shown)
99	33690	Actuator Rod (Not Shown)
100	40916	Fitting, Drain Trap (Not Shown)
101	630000502	Cover, Hopper
102	630200555	Cover, Electrical Box (Not Shown)
103	630200560	Cover, Electrical Box, Compressor (Not Shown)




Figure 3. Front end assembly exploded view and parts list

Table 2. Front end assembly exploded view and parts list

Item No.	Part No.	Description
1	638090050	Gearmotor Assembly, 115V
	638090001	Gearmotor, 115V
2	638090215	Shaft Seal Mount
3	638090051	Shaft Seal
4	638007301-030	Washer, Lower
5	638090053	E-Ring
6	638090216	Shaft Seal Seat
7	168833000	Washer, Lock 1/4 Split
8	161179001	Screw 1/4-20 x 3/4 Lg. HHMS

Table 2. Front end assembly exploded view and parts list

Item No.	Part No.	Description
9	630000505	Evaporator Assembly
10	638090213	Auger
11	638090217	Extruding Head WCC
12	638090226	Expansion Valve, Thermal
13		Not Used
14	638090211	Auger Nut
15	638090219	Bearing Nylon
16	638090220	Bearing Delrin