

PARTS LIST

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Quantity</u>
1	25715	Lamp Mounting Brkt.	2
2	30064	1/4 QC Term	1
3	30395	1/4 Term	1
4	31618	Flour Lamp Socket	2
5	31620	Flour Lamp Starter	1
6	31621	Ballast	1
7	31622	18" Day Light Bulb	1
8	32042	Starter Socket	1
9	32783	White Jumper	1
10	32784	Black Jumper	1
11	50573	Snap Bushings	2
12	70023	4-40 Keps Nut	4
13	70131	4-40 x 5/8 Screw	4
14	70215	8-32 x 1/4 Screw	2
15	70217	#8 x 1/2 Hex Self Thrd Screw	4
16	50705	Wire Ties	2
17	32990	Closed End Connector	3

INSTRUCTIONS

1. Unpack kit.
2. Disconnect dispenser from electrical power source.
3. Remove front plastic merchandiser (4 screws) and horizontal electric box cover (2 screws).
4. Insert 2 snap bushings through the bottom into the holes located 2" in from each end of the electric box.
5. Route black and white fluorescent socket (2) wires through snap bushings.
6. Insert starter socket from inside of the box through the double slotted large hole located in the left hand bottom of the box and insert black and white jumper wires into starter socket.
7. Mount the ballast with (2) slotted hex head self-threading #8 x 1/4" screws.
8. Mount (2) right angle mounting brackets with small flanges facing away from snap bushing holes. Fasten both brackets in placing using (4) #8 x 1/2" hex head self-threading screws.
9. Fasten lamp light sockets (2) to brackets using (4) 4-40 x 5/8 slotted head screws and nuts.
10. Crimp 1/4" piggyback terminal to right hand white lamp socket wire. Disconnect 1/4" white wire from lower right hand white terminal on terminal board and connect piggyback terminal in its' place and reconnect terminal to the piggyback terminal.
11. Crimp 1/4" terminal to right hand black lead from ballast connect to top (black) open terminal on terminal board.
12. Fold excess wire and wire tie (2) excess wire to existing wiring (2 places).
13. Insert starter into starter socket and light bulb in light sockets.
14. Replace electric box cover and plastic merchandiser.
15. Reconnect dispenser to power source.

DB150 LIGHTED DISPLAY KIT
 PART NUMBER 33297
 FIELD INSTALLATION INSTRUCTIONS

