



## HOW TO RESET YOUR CARD AND REMOVE IT FROM THE COMPUTER


### REMOVE YOUR FINGERPRINT FROM THE CARD




- On your PC
- Search for and open "Sign In Options"




- Select "Security Key"
- Press "Manage".




- Turn on your card.
- When the yellow light on the card starts blinking, place your finger on the fingerprint sensor




- Go to "Reset Security Key"
- Press "Reset"



- Press "Proceed"




- Turn on your card.
- When the yellow light on the card starts blinking, place your finger on the fingerprint sensor




- Press done on you pc

## HOW TO RESET YOUR CARD AND REMOVE IT FROM THE COMPUTER


### REMOVE YOUR YOUR CARD FROM THE PC



- On your PC
- Search for and open "Bluetooth Settings"




- Click on Bluetooth & devices



- Click on on the 3 ... on top right corner, on the Cardlab Access box
- Click on "Remove device"

The Access card has now been removed from the PC



### CARDLAB INNOVATION APS

HOERKAER 20, 2  
DK-2730 HERLEV  
DENMARK

EMAIL: [INFO@CARDLAB.COM](mailto:INFO@CARDLAB.COM)  
PHONE: +45 31 55 49 94