


HOW TO ENROLL YOUR ACCESS CORE CARD

CARDLAB ACCESS CARD:

Turn on the Card by pressing the Power button. Press and hold until you see the yellow light.

Red blinking light - Battery low or card error.



Green light - Card is charging
Card fully charged - green light turns of

Yellow light - Card is turned on
Yellow blinking light - Place a finger on the fingerprint sensor

Fingerprint sensor.

Windows Compatibility (Access FIDO)

Supported OS:

Windows 11 (24H2), all editions
OS build 26100.5074 (or newer) — released 29 Aug 2025

Required updates

KB5064081 (required)
KB5064401 (.NET Framework 3.5/4.8.1 cumulative — optional)


Important notes

If KB5062553 is installed, it can break the Windows Hello FIDO feature.
In this case, update to KB5064081 (or newer) to resolve.


Windows 10 is not supported.

CONNECT THE CARD TO YOUR PC


Make sure the card is charged before starting.




- On your PC.
- Search for and open "Bluetooth Settings".





- Press Add Device.



- Choose Bluetooth.




- Turn on the Card. 
Yellow light will turn on.



- Choose "Card xxxxxxxxxx"

If the Card does not show on your PC, press "Show All Devices".







- Wait for the yellow light to blinking, then place finger on the fingerprint sensor



- Press done on you pc.

HOW TO ENROLL YOUR ACCESS CORE CARD


CREATE PIN CODE:




- On your PC.
- Search for and open "Sign In Options".
- Select "Security Key".
- Press "Manage".
- Turn on your card.
- Wait for the yellow light to be blinking, then place finger on the fingerprint sensor.
- Go to "Security Key PIN".
- Press "Add" and enter a PIN chosen by you. PIN code should be 4-60 numbers or/and letters.
- Confirm the PIN.
- Press "OK".


Make sure the card is turned on, before pressing "OK"

ENROLL A FINGER;



- Under "Security Key Fingerprint" press "Set up".
- Enter your PIN code and press ok.
- Turn on the card. 
- *Repeatedly lift and rest your finger on the sensor, until setup is completed.

Note: When the yellow light on the card blinks, place your finger on the sensor and wait. When it stops, lift your finger. Repeat until the yellow light is steady.



- Press "Add another finger".
- Repeat from *

Note: It is recommended to enroll at least 1 finger from each hand.

You can enroll up to 4 fingers.

- Close "Sign in options".