


TOSOT Parts Diagram



38	Temperature Sensor
37	Electric Box Assy
36	Wire Clamp
35	Electric Box 1
34	Radiator
33	Main Board
32	Magnetic Ring
31	Electric Box Cover Sub-Assy
30	Axial Flow Fan
29	Fan Motor
28	Motor Support Spot Welding Sub-assy
27	Reactor Sub-assy
26	Reactor
25	Cover of Reactor Box
24	Top Cover Plate
23	Clapboard Sub-Assy
22	Compressor Overload Protector(External)
21	Condenser Assy
20	Rear Grill
19	Magnet Coil
18	Electric Expansion Valve Sub-Assy
17	Temp Sensor Slewing
16	Inhalation Tube Sub-assy
15	Discharge Tube Sub-assy
14	Cover of Pass Wire
13	Right Side Plate
12	Cable Cross Plate2
11	Cable Cross Plate1
10	Valve Cover
9	Valve
8	Valve
7	Valve Support
6	Compressor and Fittings

All rights reserved

TOSOT Comfort 2018

tosotcomfort.com